



NOTES:

- VISIT MB TECHNOLOGY.COM FOR THE MOST CURRENT DETAILS
- REFER TO PRODUCT DATA SHEETS ON WEB SITE FOR FURTHER INFORMATION
- PRIME MASONRY CHIMNEY WITH PERMA-A-BARRIER® WB PRIMER AS NECESSARY
- INSTALL THE ICE AND MOISTURE BLOCK IN ORDER AS SHOWN BY NUMBERS
- APPLY A BEAD OF COMPATIBLE SEALANT ALONG THE TOP TERMINATION EDGE OF ICE AND MOISTURE BLOCK ON CHIMNEY
- EXTEND ICE AND MOISTURE BLOCK FROM EAVE TO BELOW CHIMNEY AND FROM ABOVE CHIMNEY TO RIDGE
- INSTALL ICE AND MOISTURE BLOCK TO FORM WATER-SHEDDING LAPS
- REFER TO NRCA OR SMACNA FOR METAL COUNTERFLASHING AND ROOFING OPTIONS AT CHIMNEY

CHIMNEY -008

Drawings: SA108

Scale: Not to scale

Effective Date: 2/10/14

Supersedes: N/A