



NOTES:

- A. VISIT MB TECHNOLOGY.COM FOR THE MOST CURRENT DETAILS
- B. REFER TO PRODUCT DATA SHEETS ON WEB SITE FOR FURTHER INFORMATION
- C. THE DRIP EDGE IS INSTALLED OVER THE FIRST LAYER OF ICE AND MOISTURE BLOCK
- D. DO NOT INSTALL ICE AND MOISTURE BLOCK OVER CEDAR SHINGLES
- E. A SECOND LAYER OF ICE AND MOISTURE BLOCK IS INSTALLED OVER THE DRIP EDGE
- F. INSTALL THE ICE AND MOISTURE BLOCK TO FORM WATER-SHEDDING LAPS
- G. REPAIR ALL HOLES LEFT FROM REMOVAL OF TOE BOARDS, ROOF JACKS, ETC.



www.mbtechnology.com
Toll free 1-800-621-9281

EAVE OPTION -002
WITH DRIP EDGE STRIPPED-IN

Drawing: SA102

Scale: Not to scale

Effective Date: 02/10/14

Supersedes: N/A